




DSC 1616 TROUBLESHOOTING TIPS

Disarm the system Cancel an accidental alarm	CODE
Arm to Level 2—STAY	Hold STAY Button - till Beeps
Arm to Level 3—AWAY	Hold AWAY Button - till Beeps
Check system STATUS (TROUBLE LIGHT)	Press *2 for status, Panel will display a code
<p>1 - LOW BATTERY - Battery will need to be replaced , please call to schedule service</p> <p>2 - A/C POWER FAILURE - Occurs when power has gone out for more than 1 hour</p> <p>3 - TELEPHONE LINE TROUBLE - Brighthouse/Verizon Phone lines maybe out of service</p> <p>4 - FAILURE TO COMMUNICATE - May require a Service Call, may appear with CODE 3</p> <p>8 - LOSS OF SYSTEM TIME - Follow instructions below</p>	
Send a FIRE alarm	 Press and hold FIRE button for 3 seconds
Send a EMERGENCY alarm	 Press and hold EMERGENCY button for 3 seconds
Send a POLICE alarm	 Press and hold POLICE button for 3 seconds
Arm system with NO DELAY	*9 + CODE
Bypass a sensor	*1 + Sensor Number (XX) + # , then ARM
Turn Chime on / off	Hold CHIME Button
Check alarm memory	*3, Panel will display a ZONE #
Set TIME & DATE	*6 + CODE, hear 3 Beeps + Press 1 + Enter time MILITARY TIME (24:00), Enter Date mm/dd/yy Hear 3 beeps + Press ## to finish
To change MASTER CODE	*5 + OLD CODE (beep) + 40 + NEW CODE (beep)
DYNAMARK SERVICE (813) 664-0770	